

# **TELEPHONE MANAGEMENT SYSTEM**

# INSTALLATION GUIDE ASTERISK





#### **TNG Asterisk installation**

# You need to know the following before proceeding with the installation:

#### 1. Your country's international code

The international code for the country where you are based – for example South Africa's code is 27, the UK's code is 44 etc.

#### 2. Local area dialling code

This is the code that people outside your town or city will prefix to your telephone number in order to dial you. In South Africa typical examples are:

011 - Johannesburg

021 - Cape Town

031 - Durban

#### 3. Your telephone number

Your telephone number.

#### 4. The international access dialling code

The prefix(s) used to indicate that an international call is being dialled from your country. - for example South Africa's international access code is 00.

#### 5. The IP and port of the ASTERISK server as well as its login and password.

TNG will need this in order to communicate with the ASTERISK server in order to receive data.

## Installing TNG for ASTERISK

## Installing from TNG CD

When inserting the TNG CD into the PC for the first time, the installation window as shown below will appear. If it does not, browse to the CD drive and double click the tng\_setup\_xxx.exe where xxx indicates a numerical number. Click 'Next' to proceed with the installation.

#### Installing from the internet

Download the TNG Asterisk installation file from the internet and begin the installation process below.

**STEP 1:** When prompted, select "ASTERISK 30 day evaluation - Register purchase" as your installation type. Click 'Next' to proceed.



**STEP 2:** Enter your Country and Area exchange information in the fields provided. Click 'Next' to proceed.

🗞 Setup - TNG	
Country and Area Exchange Setup your dialcodes and cou	e information Intry codes
Country Information Country Code 27	e.g. for South Africa enter 27 for the UK enter 44
Exchange Information Dialling Code 021 Telephone Number 0215551234	
00	e.g. 00 (Split more than one with a ; e.g. 00;09)
	< <u>B</u> ack <u>N</u> ext > Cancel

**STEP 3:** Provide your company and support company's details in the supplied fields. Click 'Next' to proceed. If you are a registered Datatex dealer you will be required to enter your dealer code in the 'Support Company Info' section.

💊 Setup - TNG	Setup - TNG				
<b>Company Details</b> Please enter the Comp	Company Details Please enter the Company and Support Company Details				
Company Info					
Name	Company name				
Tel	0215551234	Fax	0215554321		
Email	theboss@mycompany.co.za				
Support Compar	Support Company Info				
Dealer Code	123456				
Name	Datatex Dynamics				
Tel	086 111 4351	Fax	+27 21 592 4077		
Email	support@datatex.co.za				
Installer Name	Jose				
Installer Cell	0825555555				
	•				
		< <u>B</u> ack	< <u>N</u> ext≻	Cancel	

**STEP 4:** Carefully enter the ASTERISK PABX information in the fields provided, these settings are needed to communicate with the ASTERISK box.

ABX and Communication Information Select and Setup Communication Protocol with you PABX		6
Asterisk Server IP		
127.0.0.1		
Asterisk Port	-	
12345	]	
Login Name		
Asterisk		
Password		
••••	]	
Confirm Password	1	
••••		
< <u>B</u> ack	<u>N</u> ext >	Cance

**STEP 5:** This is the detail confirmation page, it will ask you to verify all the information you have entered during the installation process. If all the information is correct, click 'Next' to proceed.

🗞 Setup - TNG	
<b>Detail Confirmation</b> Please Confirm the Details below. If incorrect click on the "Back" button and rectify.	
<ul> <li>ASTERISK INSTALLATION ************************************</li></ul>	
< <u>B</u> ack <u>N</u> ext >	Cancel

**STEP 6:** Once the previous details have been confirmed by you, you may click on 'Install' to proceed with the installation.

🗞 Setup - TNG	
<b>Ready to Install</b> Setup is now ready to begin installing TNG o	on your computer.
Click Install to continue with the installation.	
	< <u>B</u> ack Install Cancel